


Arduino 328 / Mega



Note:
This interconnect diagram works with the AeroQuad v1.1 software which can be downloaded from <http://AeroQuad.info>. Channels can be reassigned by modifying the pin out definitions in the software.